

Installation Instructions for SP084S Spot Lamp Bracket

Remove grille and overrides (if fitted the overrides can't be refitted) Remove the centre fixing nut from the bumper, fit the centre support bracket using the bumper nut and washer, bending the bracket towards the apron mark off and drill hole after offering bar up.

Loosely assemble the 2 end brackets and then check alignment. The right angled sections of the brackets bolt to the front panel and lower part of the apron.

Contents:

Lamp Bar

Right Hand Bracket

Left Hand Bracket

Center Bracket

