

[Previous](#) | [Next](#) | [Index](#)

Label Part No Description Quantity Comments

1 2A6215 Indicator switch (31945E) 1 MKI

2 47H5200 Green indicator lens 1 MKI

3 GLB280 Bulb for indicator switch 1 MKI

4 13H7778 Horn indicator switch (no wiring plug) (35840M) Use 13H7779 and adapt wire plug to bullet ends 1 MKII

5 13H7779 Horn indicator switch (with wiring plug) (39384M) 1 MKIII

6 21A2658 Indicator switch R/H side (30443H) 1 1976 to 1984

6 21A2660 Indicator switch L/H side (30445J) 1 1984-1989 plus all LHD

6 BAU5345 Indicator switch L/H side (35483A) 1 1989 on

7 37H8285 Wiper switch L/H side (30444H) 1 1976-1984

7 37H8286 Wiper switch R/H side (30446H) 1 1984-1989 plus all LHD

7 BAU5346 Wiper switch R/H side (35485A) 1 1989 on